

Dräger Flow Check Air Flow Indication

The Dräger Flow Check air current indicator produces a harmless cloud of smoke that floats freely and easily, because it has the same density as ambient air. Consequently, slight air currents become visible to easily identify leaks and test the integrity of air-tight systems.



Benefits

Better room temperature and air quality

For the optimal setting of air conditioning systems, air flows have to be located accurately and precisely. With the Flow Check air flow indicator even slightest air movements are made visible to the eye so that their origin, course and speed can be easily detected in order to ensure the functionality of ventilation systems and chimneys. The device produces a cloud of smoke, that floats freely and easily, because it has the same density as ambient air.


Harmless smoke

The Dräger Flow Check consists of one device for the smoke production and an ampoule containing smoke-generating fluid (an alcohol mixture that is harmless to the environment). A small heating element in the head of the instrument heats the fluid, which condenses on contact with the ambient air.

Easy to use

The ergonomically top-designed, hand-held instrument is of low weight and offers an optimum ease of operation. Individual little fog clouds are generated at the touch of a button. For a continuous fog generation simply press the button constantly or lock it.

Accessories



Dräger Flow-Check Ampoules

Part Number 64 00 812

Technical Data

Operating Temperature	5 °C to 40 °C
Smoke Time per Ampoule	approx. 3 min
Operating Time per Battery Charge	approx. 20 min
Ni-Cd rechargeable Battery	7.2 V; 1.4 Ah
Charging current	700 mA
Dimensions	approx. 300 mm x 200 mm x 70 mm
Weight	approx. 500 g

Ordering Information

Dräger Flow Check

Air flow indicator with one pack of ampoules, battery pack, packed in plastic case	64 00 761
--	-----------

Accessories

Flow Check ampoules (3 ampoules and 1 nozzle)	64 00 812
Battery charger, 4.8 V - 12 V / 600 mA	83 16 993
Adapter cable for in-car recharging	64 00 803
Battery pack	64 00 817

Notes

CORPORATE HEADQUARTERS
Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

MANUFACTURER
Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany

**REGION EUROPE CENTRAL
AND EUROPE NORTH**
Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany
Tel +49 461 882 0
Fax +49 461 882 2080
info@draeger.com

REGION EUROPE SOUTH
Dräger Safety France SAS
25, rue Georges Besse
92182 Antony Cedex
Tel +33 1 46 11 56 00
Fax +33 1 40 96 97 20
europe.south@draeger.com

REGION MIDDLE EAST, AFRICA
Dräger Safety AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

REGION ASIA PACIFIC
Draeger Safety Asia Pte Ltd
25 International Business Park
#04-20/21 German Centre
Singapore 609916
Tel +65 6308 9400
Fax +65 6308 9401
asia.pacific@draeger.com

**REGION CENTRAL
AND SOUTH AMERICA**
Dräger Panama S. de R.L.
Complejo Business Park,
V tower, 10th floor
Panama City
Tel +507 377 9100
Fax +507 377 9130
contactcsa@draeger.com

Locate your Regional
Sales Representative at:
www.draeger.com/contact

